



TAC-165U
1996-2004
TOYOTA TACOMA
DRIVER SIDE SHOCK MOUNT

IMPORTANT: Read and understand the General Instructions
Before Installing SafeTCap® Frame Repair Kits

Installation Instructions

- 1)** Disconnect shock absorber from the mount .
- 2)** Measure the shock mount studs location.
- 3)** Cut the original shock mount stud out from the frame.
- 4)** Place your new kit between the frame rails over the original mount.
- 5)** Using your measurement from step 2, make sure your kit is in the correct position.
- 6)** Tack weld the kit in place and check measurements again.
- 7)** Weld your new kit completely, adjust the upper tab to close any gaps.
- 8)** Rustproof the repaired area with rust inhibiting primer or undercoat.
- 9)** Reattach your shock mount absorber. A shock mount sleeve over the stud is provided only for 4wd and Prerunner Tacomas only.

