



ART-246
2001-2007
TOYOTA SEQUOIA
CENTER SECTION

IMPORTANT: Read and understand the General Instructions
Before Installing SafeTCap® Frame Repair Kits

Installation Instructions

- 1)** Jack up the front & rear of vehicle and support it on properly rated jack stands. Place rear jack stands under frame, behind rear axle. Make sure the center of vehicle is fully accessible.
- 2)** If you are repairing both sides, cut & repair one side at a time keeping one side assembled as a reference / measuring point.
- 3)** Unbolt and remove any brackets that are in the way.
- 4)** Cut away the rusted area.
- 5)** Position the kit into place and roughly mark the outline. Remove kit and grind the frame down to clean metal.
- 6)** Slide kit over frame, clamp and tack weld kit in place. If you are installing additional kits to frame, test-fit those now to make sure they all fit together properly.
- 7)** Double check all measurements and check door gaps to make sure vehicle stayed straight, then weld all edges 100% solid. If you are adding additional kits, don't weld the ends yet.
- 8)** Prime, paint or undercoat the repaired area.